



DEEP SEA ELECTRONICS PLC

DSE890 and DSE891 WebNet® Gateway Manual

Document Number: 057-165

Author: Anthony Manton



Deep Sea Electronics Plc Highfield House Hunmanby North Yorkshire YO14 0PH ENGLAND

Sales Tel: +44 (0) 1723 890099 Sales Fax: +44 (0) 1723 893303

E-mail: sales@deepseaplc.com Website: www.deepseaplc.com

DSE890 and DSE891 WebNet® Gateway® Manual

© Deep Sea Electronics Plc

All rights reserved. No part of this publication may be reproduced in any material form (including photocopying or storing in any medium by electronic means or other) without the written permission of the copyright holder except in accordance with the provisions of the Copyright, Designs and Patents Act 1988.

Applications for the copyright holder's written permission to reproduce any part of this publication must be addressed to Deep Sea Electronics Plc at the address above.

Any reference to trademarked product names used within this publication is owned by their respective companies.

Deep Sea Electronics Plc reserves the right to change the contents of this document without prior notice.

Amendments since last publication

Issue No.	Comments
1	First release.
1.1	Corrected part numbers of antennae.
1.2	Added more general detail to all areas.
2	Added DSE891Ethernet only gateway.
3	Added 7400 series, 8610 and "format file system" description.
4	Added support for more module types.
5	Updated with new graphical style (V3 DSEGateway®) and additional detail in most areas.
6	Updated to show IE 9 is not supported.
	Added "Advanced Instrumentation".
	Corrected a number of minor typos.
	Corrected digital input specification and typical wiring diagram.
7	Added Snapshot information.

Continued overleaf...

Issue No.	Comments
8	Added ATS products to the compatibility table.
8.1	Added DSE7310 MKII and DSE7320 MKII products to the compatibility table.
8.2	Added DSE8610 MKII to the compatibility table.
9.0	Added UL rating.
	Revised Adding Controller to the DSE Gateway Description.
	Removed Device compatability table.
	Revised/simplified Bootloader and Firmware upgrade procedure.
	Amended user connections - terminals one and two wrong way round.

Typeface : The typeface used in this document is *Arial*. Care must be taken not to mistake the upper case letter I with the numeral 1. The numeral 1 has a top serif to avoid this confusion.

Table of Contents

1	INTRODUCTION	6
2	SPECIFICATIONS	8
-		0
		•••••
		0
		0
		ð
		ð
		8
		8
	2.4 IERMINAL SPECIFICATION	9
	2.5 SIM CARD CONNECTOR	9
	2.6 GSM CONNECTOR	9
	2.7 GPS CONNECTOR	10
	2.8 USB HOST CONNECTOR	11
	2.9 RS232 CONNECTOR	11
	2.9.1 NULL MODEM CABLE WIRING	11
	2.10 RS485 CONNECTOR	12
	2.11 ETHERNET CONNECTOR	12
	2.12 DIMENSIONS AND MOUNTING	13
~		
3	S INSTALLATION	. 14
	3.1 USER CONNECTIONS	14
	3.1.1 CONNECTOR A – DC SUPPLY AND CONFIGURABLE OUTPUTS	14
	3.1.2 CONNECTOR B – RS485	14
	3.1.3 GSM & GPS CONNECTIONS (DSE890 3G GATEWAY ONLY)	14
	3.2 SIM CARD HOLDER (DSE890 3G GATEWAY ONLY)	15
	3.2.1 HOW TO INSERT THE 3G (OR 2G) GPRS SIM CARD	15
	3.3 TYPICAL WIRING DIAGRAM	16
	3.4 SYSTEM OVERVIEW	16
	3.5 TYPICAL CONNECTION TO DSE CONTROLLERS	17
	3.5.1 ADDING THE CONTROLLER TO THE DSE GATEWAY®	17
	3.5.2 DEVICE COMPATIBILITY	18
	3.5.3 USB (SINGLE CONTROLLER)	19
	3 5 4 BS232 (SINGLE CONTROLLER)	19
	3 5 5 R\$485 (SINGLE CONTROLLER)	20
	3.5.6 PS485 (MILLITIDI E CONTROLLER)	20
	2.5.7 ETHEDNET (SINCLE CONTROLLER)	20
		∠1 21
		∠I
		22
		22
	3.6.2 FIREWALL SETTINGS	22
	3.6.3 VIA ETHERNET	23
	3.6.4 VIA GPRS (DSE890 3G GATEWAY ONLY)	23
4	CONTROLS AND INDICATIONS	. 24
	4.1 RESET PUSHBUTTON	
	4.2 LED INDICATIONS	24
_		
5	5 SETUP	. 25
	5.1 BROWSER COMPATIBILITY	25
	5.1.1 GOOGLE CHROME	25
	5.1.2 INTERNET EXPLORER	25
	5.1.3 MOZILLA FIREFOX	25
	5.1.4 SMARTPHONE BROWSERS	25
	5.2 CONNECTING TO THE GATEWAY MANAGEMENT PAGES	26
	5.3 STATUS	
	5.3.1 INFO	27
		6 1

	5.3.4	LOCATION	31
	5.3.5	I/O	31
	5.3.6	MODBUS	31
	5.3.7	DATA USAGE	32
5	.4 CO	NFIGURATION	33
	5.4.1	INFO	33
	5.4.2	NETWORK	34
	5.4.3	GSM (DSE890 GATEWAY ONLY)	35
	5.4.4	LOCATION	36
	5.4.5	I/O	37
	5.4.6	ТІМЕ	37
	5.4.7	FILE SYSTEM	38
	5.4.8	BOOTLOADER UPGRADE	
	5.4.9	FIRMWARE UPGRADE	40
_	5.4.10	HOW TO FORMAT A USB FLASH MEMORY STICK TO FAT	40
5	.5 MO		
	5.5.1	DSEWEBNET	
	5.5.2	CUSTOM INSTRUMENTS	
	5.5.3	MODBUS	47
6	FAUL	۲ DIAGNOSIS	49
7	MAINT	ENANCE, SPARES, REPAIR, AND SERVICING	51
8	WARR	ANTY	51
•			
9	DISPO	25AL	51

1 INTRODUCTION

This document details the installation requirements of the DSE890 and DSE891 WebNet® Gateway (DSEGateway[®]). The manual forms part of the product and must be kept for the entire life of the product. If the product is passed or supplied to another party, ensure that this document is passed to them for reference purposes.

This is not a *controlled document*. Any future updates of this document are included on the DSE website at www.deepseaplc.com

The DSEGateway[®] is used in conjunction with supported DSE controllers to provide monitoring and communications to a DSEWebNet® Server.

The DSEGateway[®] communicates to the connected controller(s), monitoring the instrumentation and operating state. If this data changes, the new data is logged in the DSEGateway[®]'s memory. Depending upon configuration, at regular intervals the logged data is transmitted by GPRS or Ethernet to the DSEWebNet® Server.

The DSE890 3G Gateway connects to the DSEWebNet® Server by integral Ethernet connection and GPRS (2G or 3G mobile internet). Additionally, DSE890 includes GPS (satellite location) functionality. This is most suited for remote and/or mobile locations.

The DSE891 Ethernet Gateway connects to the DSEWebNet® Server by integral Ethernet connection only. This is most suited for fixed installations where an ADSL / DSL cable broadband service is available.

The DSEWebNet® Server is then interrogated via an internet connected PC and web browser or SmartPhone (App or Web browser) to allow viewing of historic data or for live viewing/control.

DSEGateway® is setup using a PC and network cable as detailed later in this document.

Additionally the DSEWebNet® server can send emails if configured to do so.

Where DSE890 3G Gateway is used in conjunction with an appropriate SIM card, the DSEWebNet[®] server can be configured to use the DSE890 Gateway to send SMS messages. This feature is not available when using DSE891 Ethernet Gateway.

For details on accessing the DSEGateway[®] using the DSEWebNet[®] system, refer to DSE publication 057-168 DSEWebNet[®] Software Manual available from the DSE website at www.deepseaplc.com.

1.1 **BIBLIOGRAPHY**

This document refers to and is referred to by the following DSE publications which is obtained from the DSE website www.deepseaplc.com

Dse Part	Description
053-140	DSE890 and DSE891 Installation Instructions
057-168	DSEWebNet [®] Software Manual
057-156	DSE334 Configuration Suite PC Software Manual
057-237	DSE335 Configuration Suite PC Software Manual
057-187	DSEL400 & DSEL401 Configuration Suite PC Software Manual
057-222	DSEL401 MKII Configuration Suite PC Software Manual
057-178	DSE4310 & DSE4320 Configuration Suite PC Software Manual
057-093	DSE4410 & DSE4420 Configuration Suite PC Software Manual
057-172	DSE4510 & DSE4520 Configuration Suite PC Software Manual
057-201	DSE4610 & DSE4620 Configuration Suite PC Software Manual
057-114	DSE6010 & DSE6020 Configuration Suite PC Software Manual
057-223	DSE6010 MKII & DSE6020 MKII Configuration Suite PC Software Manual
057-096	DSE6110 & DSE6120 Configuration Suite PC Software Manual
057-224	DSE6110 MKII & DSE6120 MKII Configuration Suite PC Software Manual
057-117	DSE7110 & DSE7120 Configuration Suite PC Software Manual
057-185	DSE7110 MKII & DSE7120 MKII Configuration Suite PC Software Manual
057-077	DSE72xx & DSE73xx Configuration Suite PC Software Manual
057-243	DSE7310 MKII & DSE7320 MKII Configuration Suite PC Software Manual
057-160	DSE7410 & DSE7420 Configuration Suite PC Software Manual
057-119	DSE8610, DSE8620 & DSE8660 Configuration Suite PC Software Manual
057-238	DSE8610 MKII Configuration Suite PC Software Manual
057-164	DSE8810 Configuration Suite PC Software Manual
057-174	DSE8860 Configuration Suite PC Software Manual

2 SPECIFICATIONS

2.1 TEMPERATURE

2.1.1 OPERATING TEMPERATURE

Minimum Temperature	-30 °C (-22 °F)
Maximum Temperature	UL enviroment rating = +50 °C (122 °F)
	None UL environment rating = $+60 \degree C (140 \degree F)$

2.1.2 STORAGE TEMPERATURE

Minimum Temperature	-40 °C (-40 °F)
Maximum Temperature	+80 °C (176 °F)

2.2 POWER SUPPLY

Minimum Supply Voltage	8 V continuous, 4 V for up to 5 minutes.
Cranking Dropouts	Able to survive 0 V for 100 mS providing the supply was at least 8 V
	before the dropout and recovers to 8 V afterwards.
Maximum Supply Voltage	32 V continuous (transient protection to 64 V)
Power Up Current	3 A transient inrush at initial power up.
Typical Operating Current	630 mA at 12 V DC, 315 mA at 24 V DC

2.3 CONFIGURABLE I/O

Number 4 configurable general purpose input / outputs.
--

2.3.1 OUTPUTS

Туре	Manually operated in the Site I/O section of the DSEWebnet® System.
Rating	2 A DC Resistive at Supply Voltage.

2.3.2 INPUTS

Туре	Switch to plant supply positive to activate.
Low level threshold	2.1 V minimum.
High level threshold	6.6 V maximum.
Maximum input voltage	+50 V DC with respect to plant supply negative.
Minimum input voltage	-24 V DC with respect to plant supply negative.
Contact wetting current	7 mA typical.
Open circuit voltage	12 V typical.

2.4 TERMINAL SPECIFICATION

Connection Type	Screw terminal, rising clamp, no internal spring
Min Cable Size	0.5 mm² (AWG 20)
Max Cable Size	2.5 mm² (AWG 14)

2.5 SIM CARD CONNECTOR

ONOTE: GSM / GPRS service is not available with DSE891 Ethernet Gateway.

Provided to allow the DSE890 3G Gateway to be connected to a GPRS (internet over GSM) network. 3G or 2G SIM cards are supported. (Optional for use with GPRS support).

2.6 GSM CONNECTOR

ONOTE: GSM / GPRS service is not available with DSE891 Ethernet Gateway.

	DSE890 GSM Connector	Required Antenna Cable Connector
GSM	SMA FEMALE	SMA MALE
GSM	(Outside thread, female central receptacle)	(Inside thread, male central pin)

ANOTE: DSE stock a GS<u>M antenna suitable for this purpose</u>. Part number 020-141.

NOTE: DSE stock a Combined GSM/GPS antenna suitable for this purpose. Part number 020-150.

DSE testing has shown that separate GSM and GPS antennae tend to give better results than a combined antenna where a clear view of the sky is not available.

2.7 GPS CONNECTOR

ANOTE: GPS service is not available with DSE891 Ethernet Gateway.

	DSE890 GPS Connector	Required Antenna Cable Connector
GPS	SMA MALE	SMA FEMALE
GPS	(Inside thread, male central pin)	(Outside thread, female central receptacle)

ANOTE: DSE stock a GPS antenna suitable for this purpose. Part number 020-130.

NOTE: DSE stock a Combined GSM/GPS antenna suitable for this purpose. Part number 020-150.

DSE testing has shown that separate GSM and GPS antennae tend to give better results than a combined antenna where a clear view of the sky is not available.

2.8 USB HOST CONNECTOR

This USB type A socket provides support for connection to one DSE controller. Use USB type A to USB type B cable.

ONOTE: DSE stock a USB suitable cable for this purpose. Part number 016-125.

2.9 RS232 CONNECTOR

This socket provides support for connection to one DSE controller.

Pin No	Notes
1	Received Line Signal Detector (Data Carrier Detect)
2	Received Data
3	Transmit Data
4	Data Terminal Ready
5	Signal Ground
6	Data Set Ready
7	Request To Send
8	Clear To Send
9	Ring Indicator



View looking into the male connector on the module

2.9.1 NULL MODEM CABLE WIRING



DSE Controller with RS232





DSEGateway®

2.10 RS485 CONNECTOR

This socket provides support for connection to a maximum of 5 (five) DSE controllers in a daisy chain RS485 network.

Ensure termination resistors (120 Ω) are fitted as shown to the ends of the link as per RS485 standard.

Pin No	Notes	
A (-)	Two core screened twisted pair cable.	
B (+)	Recommended cable type - Belden 9841	
SCR	Max distance 1200m (1.2km) when using Belden 9841 or direct equivalent.	



2.11 ETHERNET CONNECTOR

The DSEGateway[®] module is fitted with an autosensing ethernet socket. This can be utilised in a number of ways. See section entitled *Typical Connection to DSE controllers*, subsection *Via Ethernet* for further details.



NOTE:DSE Stock a 2m (2yds) Ethernet Cable – Part number 016-137. Alternatively they can be purchased from any PC or IT store. As the Gateway is autosensing, either a 'straight through' or 'crossover' cable can be used. The diagram above shows a 'straight though' cable.

2.12 DIMENSIONS AND MOUNTING

Overall Size	85 mm x 149 mm x 51 mm
	(3.35" x 5.85" x 2.01")
Weight	120 g
	(4.23 oz.)
Mounting Type	DIN rail or chassis mounting
DIN Rail Type	EN 50022 35 mm type only
Mounting Holes	M4 clearance
Mounting Hole Centres	73 mm x 137 mm
	(2.89" x 5.39")
BS EN 60529	IP21
(Degrees Of Protection Provided By	
Enclosures)	
UL508	Enclosure type 1 (indoor use only)
Nema Rating	





Dimensions in mm

3 INSTALLATION

The DSEGateway[®] is designed to be mounted within a control panel, either on the panel DIN rail utilising the integral mounts, or chassis mounted, utilising the mounting holes. For dimension and mounting details, see the section entitled *Specification, Dimensions* elsewhere in this document.

3.1 USER CONNECTIONS

3.1.1 CONNECTOR A – DC SUPPLY AND CONFIGURABLE OUTPUTS

Terminal	Function	Recommended Size
1	DC supply negative	1.0 mm² (AWG18)
2	DC supply positive	1.0 mm² (AWG18)
3	Configurable Input / Output (I/O)	0.5 mm² (AWG20)
4	Configurable Input / Output (I/O)	0.5 mm² (AWG20)
5	Configurable Input / Output (I/O)	0.5 mm² (AWG20)
6	Configurable Input / Output (I/O)	0.5 mm² (AWG20)

3.1.2 CONNECTOR B – RS485

Terminal	Function	Recommended Size
А	RS485 A	0.5 mm² (AWG20)
В	RS485 B	0.5 mm² (AWG20)
SCR	RS485 Screen	

3.1.3 GSM & GPS CONNECTIONS (DSE890 3G GATEWAY ONLY)

Connector Designation	DSE890 Socket Type	Required Antenna Cable Connector
GSM	SMA FEMALE	SMA MALE
	(Outside thread, female central receptacle)	(Inside thread, male central pin)
GPS	SMA MALE	SMA FEMALE
	(Inside thread, male central pin)	(Outside thread, female central receptacle)

3.2 SIM CARD HOLDER (DSE890 3G GATEWAY ONLY)

3.2.1 HOW TO INSERT THE 3G (OR 2G) GPRS SIM CARD



Pull back the upper cover, it clicks as it unlocks.



Open the SIM card holder, it hinges towards you.



Slide in the SIM card, ensuring the "edge cutout" is as shown



Close the cover, press it down and slide it as shown until it clicks into place.

3.3 TYPICAL WIRING DIAGRAM



TERMINALS SUITABLE FOR 22–16 AWG (0.6mm² – 1.3mm^2) FIELD WIRING TIGHTENING TORQUE = 0.8Nm (7lb-in)

NOTE 1

A 120 OHM TERMINATION RESISTOR MUST BE FITTED IF IT IS THE FIRST OR LAST DEVICE ON AN RS485 LINK NOTE 2

GSM & GPS CONNECTIONS NOT AVAILABLE ON MODEL 0891

3.4 SYSTEM OVERVIEW



3.5 TYPICAL CONNECTION TO DSE CONTROLLERS

This section shows how to connect DSE controllers to the gateway device. For details on how to connect the gateway to the server, see section entitled *Typical connections to gateway server*.

3.5.1 ADDING THE CONTROLLER TO THE DSE GATEWAY®

To ensure newly added controllers are recognised by the DSEGateway[®], the following steps must be followed. Failure to do so may result in communications failure indicated by a Red LED status in relation to the required comm's port.

The DSEGateway[®] is factory set to accept connection via the USB port. If this is not the comm's type to be used, the entry must be deleted in the *Module Connections* page of the DSEGateway[®]. It must then be re-configured to suit the Genset comm's type requirement (RS232/485 or ethernet). The process below explains how this can be achieved.

- Connect to the DSE89X configuration page as described in the set-up section of this manual.
- Select *Modules Connection* and configure each port to match the controller being connected.
- Once the configuration port settings have been entered, click 'Apply' and click 'Save config'.
- Remove the DC supply from the DSEGateway[®].
- Connect the new controller to the chosen communications port.
- Apply the DC supply to the controller being added (and any other controllers in the system).
- Re-apply the power supply to the DSEGateway[®].
- For a short time (up to 5mins), the link light will remain red. The link LED then illuminates green when connection to the DSEWebNet[®] server is established. During a first time install, if no module is connected to the DSE89X then the link LED will remain continously red.
- If the controller is connected and configured correctly for the DSEGateway[®] then the template file is downloaded from the DSE server. Once downloaded the associated configuration comminucations ports begin to flash green.
- Any unused communication ports must be deleted from the module. This prevents the DSE89X from continuously searching for unconnected modules.



Please Note; For more details on accessing the DSEGateway[®] using the DSEWebNet[®] system, refer to DSE publication 057-168 DSEWebNet[®] Software Manual available from the DSE website at www.deepseaplc.com.

3.5.2 DEVICE COMPATIBILITY

For up to date information regarding device compatibility contact DSE technical support:

Tel: +44 1723 890099 Fax: +44 1723 893303 Email: <u>support@deepseaplc.com</u> Web: <u>https://www.deepseaplc.com/support</u>

3.5.3 USB (SINGLE CONTROLLER)

USB connection utilises a standard USB A – USB B cable.

NOTE: DSE Stock a 2m (2yds) USB Cable DSE Part No 016-125. Alternatively they can be purchased from any PC or IT store.



3.5.4 RS232 (SINGLE CONTROLLER)

RS232 connection utilises a standard RS232 Null modem (crossover) cable.



3.5.5 RS485 (SINGLE CONTROLLER)

RS485 connection utilises twisted pair RS485 cable with 120 Ω termination resistors as per RS485 standard.



3.5.6 RS485 (MULTIPLE CONTROLLER)

RS485 connection utilises twisted pair RS485 cable with 120 Ω termination esistors as per RS485 standard.



NOTE: DSE stock and supply Belden cable 9841 which is a high quality 120 Ω impedance cable suitable for RS485 use (DSE part number 016-030)

3.5.7 ETHERNET (SINGLE CONTROLLER)

Ethernet connection utilises a standard Ethernet cable with RJ45 connectors.



3.5.8 ETHERNET (MULTIPLE CONTROLLER)

Ethernet connection utilises a standard Ethernet cable with RJ45 connectors.



3.6 TYPICAL CONNECTION TO DSEWEBNET® SERVER

The DSEGateway[®] communicates with the DSEWebNet® Server at regular (configurable) intervals to upload its logged data to the main database.

This connection is via Ethernet (or internet) or GPRS (internet over the GSM cellular network).

ONOTE: GSM / GPRS service is not available with DSE891 Ethernet Gateway.

3.6.1 DSEWEBNET® SERVER CONNECTION INFORMATION

This sections contains information that may be useful to the I.T. or Network Managers on sites where the DSEGateway[®] is installed.

Item	Description
Transmission Protocol	All the data is sent using HTTP either on port 80 or 83. There is no 'read'
	All data transfer streaming is initialized by the DSEGaleway ³ .
	on the DSEWebNet® Server.
Data Encryption	All the data is sent using a web socket protocol connection for real time
	data and http posts for historic data.
	The data for both of these is not encrypted but is not human readable.
	i.e. numbers and letters only rather than words.
	The DSEGateway [®] constantly contacts the DSEWebNet® Server, no
	connection is initialized by the Server.
Access Security	All users have a different php session with "session takeover" attack
	prevention taken in to account.
	The passwords are hashed in MD5 format, the rest is in clear text.

3.6.2 FIREWALL SETTINGS

To allow the DSEGateway[®] to communicate with the DSEWebNet® Server it is important than any network firewalls do not block access to the relevant ports.

This is particularly important with wired connection to the internet however usually GSM networks do not include a network firewall.

The DSE Server names and port numbers are listed below:

Domain name	Port
www.dsewebnet.com	80
realtime.dsewebnet.com	83
historic.dsewebnet.com	80

To provide the best possible service, it is recommended that any firewall is configured to allow access to all subdomains on the *dsewebnet.com* domain as follows:

Domain name	Ports
*.dsewebnet.com	80, 83

3.6.3 VIA ETHERNET



3.6.4 VIA GPRS (DSE890 3G GATEWAY ONLY)

ONOTE: GSM / GPRS service is not available with DSE891 Ethernet Gateway.

A 2G or 3G GSM SIM card can be fitted into the DSE890. This provides GRPS connection to the DSEWebNet $\mbox{\ensuremath{\mathbb{S}}}$ Server.



4 CONTROLS AND INDICATIONS

4.1 RESET PUSHBUTTON

The reset push button, accessible by removing the front cover or via the small hole and by using an insulated narrow point, is provided to set the device back to factory settings.



Press and hold the button to activate the reset sequence :

- 1. Press and HOLD the reset pushbutton.
- 2. All LEDs light YELLOW for a short time.
- 3. All LEDs extinguish for a short time.
- 4. LEDs illuminate one at a time LED4, LED3, LED2, LED1.
- 5. All LEDs illuminate YELLOW.
- 6. Reset has completed and the reset push button can be released.

Once reset, the Gateway must be reconfigured It's factory set IP address is 192.168.1.100. Username: Admin, Password Password1234

4.2 LED INDICATIONS

LED	Function	Colour	Action
1	Server Status	Red	No connection to DSEWebNet® Server
		Green	Connected to DSEWebNet® Server and all
			configured ports are OK
2	USB Host Status	Red	No Unit Detected
		Green	Data transfer OK
3	RS485 Status	Red	No Unit Detected
		Green	Data transfer OK
4	RS232 Status	Red	No Unit Detected
		Green	Data transfer OK

5 SETUP

The DSEGateway[®] is setup using a PC with web browser and a 'straight through' or 'crossover' network cable.

5.1 BROWSER COMPATIBILITY

5.1.1 GOOGLE CHROME

The DSEGateway® management pages are optimised for Google Chrome web browser.

5.1.2 INTERNET EXPLORER

Internet Explorer 10 and above

The DSEGateway® management pages are optimised for Internet Explorer 10 and above.

Internet Explorer 9 and earlier

Internet Explorer 9 and earlier versions are not supported.

5.1.3 MOZILLA FIREFOX

The DSEGateway® management pages are optimised for Mozilla Firefox

5.1.4 SMARTPHONE BROWSERS

Smartphone browsers are not supported by the DSEGateway® management pages.

5.2 CONNECTING TO THE GATEWAY MANAGEMENT PAGES

Consult the company IT department before making changes to PC network settings.

Connect the DSEGateway[®] ethernet port directly to the PC Ethernet port.

It is possible to sse either a 'straight through' or 'crossover' network cable.

Set the PC IP address as shown.

Using Google Chrome, Microsoft Internet Explorer or Mozilla Firefox, enter the IP address of the gateway.

Enter the username and password of the Gateway :

ANOTE: Password is CASE SENSITIVE.

For further details refer to the following DSE publications available from our website : www.deepseaplc.com

057-168 DSEWebNet® Software Manual

Factory Settings		
IP Address	Username	Password
192.168.1.100	Admin	Password1234



5.3 STATUS

The Status pages show information that can be used for diagnostics and give a level of confidence that the system is working as expected. Along with DSEGateway[®] physical information, the displays also indicate the state of the various communication ports in use.

The information is separated into subtabs:

Info Network Location IO MODBUS Data Usage

Depending upon the type of the DSEGateway®, different information is displayed.

5.3.1 INFO

DSE				
DSE 0891-01 Gateway	/	192.168.1.200 25/02/2014 11:09:10 V3.0.27		
Status	Info Network Location IO	MODBUS Data Usage		
	Model	0891-01		
Configuration	Gateway ID	117814077045A1		
	Software Version	3.0.27		
Modules Connection	Bootloader Version	2.0.0		
Modules Connection	Server URL	www.dsewebnet.co.uk		
	Site Name	DSE Generator House		
Parameter	Description			
Model	Model number of	the DSEGateway®		
Gateway ID	Unique identificat	Unique identification number of the DSEGateway [®] . This is used when adding		
	the DSEGateway	[®] to the DSEWebNet [®] Server.		
Software Varaian	Chowe the active	vice vice of the DSEC stowers		

	the DSEGateway [®] to the DSEWebNet [®] Server.
Software Version	Shows the software version of the DSEGateway [®] .
Bootloader Version	Shows the software bootloader version of the DSEGateway®.
Server URL	Shows the configured address that the DSEGateway® is configured to
	communicate with. The DSEWebNet [®] Server is located at
	www.dsewebnet.co.uk
Site Name	Configured name of the site. This is configured under Configuration Info.

Setup

5.3.2 NETWORK

Shows the current network settings in use on the DSEGateway[®] and a status of the connection to the DSEWebNet[®] Services.

DSE 0891-01 Gateway			192,168 1 200 25/02/	2014 11:14:24 V3 0 27
Status	Network Location IO MODBU	S Data Usage		
	ttain IP Method	Static		J
Configuration	P Address	192.168.1.200		
Si	ubnet	255.255.255.0		
Modules Connection	NS ateway IP Address	192.168.1.1		
	/eb Config Port	8080		
M	AC Address			
	ostname	DSEGateway		
	URL www.dsowebn	et co.uk	IP 193 200 80 112	Status
	realtime.dsew	ebnet.com:83	193.200.80.114	ок
	historic.dsewe	bnet.com:80	193.200.80.112	ок
		Advanced		
Click Ac	<i>lvanced</i> to open and	l close a		
diagnos	tic window to help tr	oubleshoot		
network	connection issues	00010011001		
Hetwork				
Parameter	Description			
Attain IP Method	Shows the type of	f IP address assigne	ed to the DSEGatewa	y [®] Ethernet
	Port.	Ŭ		
	Static: Static IP a	ddress, manually e	ntered.	
	DHCP: IP address	s assigned by the n	etwork DHCP server.	
IP Address	IP address curren	tly being used by th	ne DSEGateway®'s Et	hernet Port.
Subnet	Subnet Mask for t	the DSEGateway®'s	Ethernet Port.	
DNS	DNS (Domain Na	me Service) setting	for the DSEGateway	[®] 's Ethernet
	Port.	, 3	,	
Gateway IP Address	The IP address lo	cation of the interne	et router currently use	d by the
, ,	DSEGatewav [®] 's B	Ethernet Port to con	nmunicate with the DS	SEWebNet®
	Server.			
Web Config Port	The TCP Port Nu	mber currently in us	e by the DSEGatewa	v®'s Ethernet
	Port to serve the	Web Management	Pages.	,
MAC Address	Unique Hardware	Identification numb	er of the DSEGatewa	v®'s Ethernet
	Port.			.,
Hostname	Shows the curren	tly configured Hostr	name of the DSEGate	wav®'s Ethernet
liounanio	Port.	ay configured floor		way o Euloniot
URL. IP. Status	Shows the status	of connection to the	e DSEWebNet [®] Serve	er.
, ,	- The connect	tion is made to the	respective port of the	DSF\//ahNlat®
	= The respect	ive port of the DSE	NebNet [®] Server cann	ot be reached.
	This may be a loc	al firewall issue (se	e below)	

5.3.2.1 ADVANCED

The advanced section shows diagnostic information that may assist DSE Technical Support in the case of GSM connection issues.

Example showing a successful connection to a Network:

[04:58:04]->Registering	with GUI server
[04:58:04]->register Sta	atus OK
[04:58:04]->Aquired Re	al time server Address: realtime1.dsewebnet.com:83
[04:58:33]->Registering	with GUI server
[04:58:33]->register Sta	atus OK
[04:58:33]->Aquired Re	al time server Address: realtime2.dsewebnet.com:83
[04:58:36]->Registering	g with GUI server
[04:58:36]->register Sta	atus OK
[04:58:36]->Aquired Re	al time server Address: realtime.dsewebnet.com:83
[04:57:38]->Aquired Hi	storic server Address: historic1.dsewebnet.com:80

For details of required firewall settings to allow connection to the DSEWebNet[®] server, see the section entitled *Typical Connection to DSEWebNet Server* elsewhere in this document.

5.3.3 GSM (DSE890 GATEWAY ONLY)

NOTE: GSM status is not available with DSE891 Ethernet Gateway.

Provides diagnostic information for the GSM connection.

DSE DSE 0890-01 Gatewa	y		192.168.1.100 27/03/2014 13:49:04 V3.0.27
Status	Info Network GSM Locati	on IO MODBUS Data Usage	
	IMEI	259998041291008	
Configuration	GSM IP	172.26.55.14	
	Connection Type	UTRAN	
Modules Connection	Provider	T-Mobile UK	
Save Config	Signal Strength		
		Advanced	
Click A	Advanced to open a	and close a	

connection issues (DSE890 only)

Parameter	Description
IMEI	IMEI number of the GSM communications device integrated within the DSE890
	Gateway.
GSM IP	IP address obtained from the GSM network provider. Unless a specifically
	purchased fixed IP address has been obtained from the SIM card provider, this
	number is dynamically provided by the GSM network operator.
Connection Type	Type of connection made to the GSM network. This changes from area to area
	depending upon local network provision.
Provider	The name of the GSM network currently connected.
Signal Strength	A representation of the GSM signal strength. This does not represent the
	quality of the GPRS (cellular internet) connection.
	No green bars indicates poor reception. Move the antenna to a better location.

5.3.3.1 ADVANCED

The advanced section shows diagnostic information that may assist DSE Technical Support in the case of GSM connection issues.

Example showing a successful connection to a GSM Network, resulting in an IP address being assigned to allow connection.



5.3.4 LOCATION

Shows the current location of the DSEGateway[®]. For DSE890, this is either a fixed or GPS devised location, depending upon configuration. For DSE891 this is a fixed (user configured) location.

DSE DSE 0891-01 Gatewa	Ŋ		192.168.1.200 25/02/2014 11:17:14 V3.0.27
Status	Info Network Location	n IO MODBUS Data Usage	
	Latitude	54.176582	
Configuration	Longitude	-0.311036	
Modules Connection			

5.3.5 I/O

Shows the state of the DSEGateway[®] I/O (Inputs/Outputs). These are configured in the *Configuration* | I/O tab.

DSE DSE 0891-01 Gatewa	v				192.168.1.200 25/02/2014 11:49:31 V3.0.27
Status	Info	Network Location IO	MODBUS	Data Us	age
	Index	Name	ю	Status	
Configuration	1	Fuel Tampered with	In	۲	
	2	Digital IO B	Out		
Modules Connection	3	Digital IO C	Out		
	4	Digital IO D	Out		

5.3.6 MODBUS

Shows the status of the data transfer between the DSEGateway[®] and the connected controller(s). When operating correctly, the packets *Received* increment as the packets *Sent* increase. Unconfigured ports show 0 (zero) for both *Sent* and *Received* as no communications takes place.

DSE DSE 0891-01 Gateway	/			192.168.1.200 25/02/2014 11:55:14 V3.0.27
Status	Info Network Locat	ion IO MODBU	S Data Usage	
	USB Host Packets	Sent	0	
Configuration		Received	0	
	RS232	Sent	0	
Modules Connection		Received	0	
		Sent	3281	
K5485	Received	3280		
		Sent	0	
	TCP HOST PACKETS	Received	0	

Setup

5.3.7 DATA USAGE

Shows the amount of data sent by the DSEGateway[®] to the DSEWebNet[®] server. This is useful when determining if the correct package has been purchased from the SIM Card or internet provider.



5.4 CONFIGURATION

DSEGateway[®] configuration is separated into separate pages.

ANOTE: Upon changing a parameter on any of the pages, the *Apply* button must be pressed before exiting the current page. This stores the new settings and allows settings on other pages to be changed. A new button, *Save Config* becomes available after *Apply* is clicked.



5.4.1 INFO

DSE DSE 0891-01 Gatewa	y		192.168.1.200 25/02/2014 12:02:38 V3.0.27
Status	Info Network Location IO	Time File System	
Configuration	Username: Security Code	admin Password1234	
Modules Connection	Site Name Server Url	DSE Generator House www.dsewebnet.co.uk Apply	

Parameter	Description
Username	Factory setting: Admin
	A NOTE: Username is CASE SENSITIVE.
Security Code	Factory setting: Password1234
	Security Code is required to gain access to these management pages and also
	to add connected devices to the DSEGateway [®] .
	A NOTE: Security Code is CASE SENSITIVE.
Site Name	A name to easily identify the site. This name is shown when viewing the map of
	sites on the DSEWebNet [®] server.
Server URL	Address of the DSEWebNet [®] server.
Apply	Store the changes to the DSEGateway [®] .

Setup

5.4.2 NETWORK

Consult with the IT/Network manager of the site that the DSEGateway $^{\ensuremath{\mathbb{B}}}$ is connected to before making any changes to these settings.

DSE			
DSE 0891-01 Gatewa	iy		192.168.1.200 25/02/2014 12:06:18 V3.0.27
Status	Info Network Location IO	Time File System	
	DHCP Enabled		
Configuration	Static IP	192.168.1.200]
Modules Connection	Subnet Mask	255.255.255.0]
Modules Connection	Gateway IP	192.168.1.1]
	DNS IP	192.168.1.1]
	Host Name	DSEGateway]
	WebConfig Port	8080]
		Apply	

Parameter	Description
DHCP Enabled	\square = The DSEGateway [®] requests network settings from a DHCP server.
	\Box = The DSEGateway [®] 's network settings must be entered manually.
Static IP	(Factory setting 192.168.1.100)
Subnet Mask	(Factory setting 255.255.255.0)
Gateway IP	IP address of the internet router that the DSEGateway [®] is connected to.
DNS IP	IP address of the Domain Name Service. Usually this is the same as the
	Gateway IP.
Host Name	Hostname of the device. Used to identify the DSE Gateway® on the network.
	Give this a meaningful name to assist the network IT manager to recognise the
	device on the network.
	Some network configurations may require this to be a unique name, not used
	by any other device on the network. Consult the network manager for more
	information.
WebConfig Port	The TCP Port Number the DSEGateway [®] serves the webmanagement pages
	on.
	Consult the network manager for more information.

5.4.3 GSM (DSE890 GATEWAY ONLY)

ANOTE: GSM configuration is not available with DSE891 Ethernet Gateway[®].

DSE DSE 0890-01 Gatewa	Ŋ		192.168.1.100 27/03/2014 14:01:20 V3.0.27
Status	Info Network GSM Location	on IO Time File System	
Configuration	Use GSM Operator		Г
Modules Connection	PIN		
	APN	Internet	
Save Config	User Name	web	
	Password	web	
	Message Centre		
		Apply	

Parameter	Description		
Use GSM	Selection for connection to DSEWebNet® Server:		
	\square = GSM (GPRS) over 2G or 3G network depending upon installation of a suitable SIM card		
	\Box = Ethernet via external broadband modem connection.		
Operator	Name of the GSM network operator. This must be the exact name as provided by the SIM card supplier. If this is not provided, leave this box empty.		
PIN	PIN of the SIM card (where used).		
	NOTE: When using the SIM card from a cellphone, this is the PIN number of the SIM card, NOT the PIN number of the cellphone!		
	A NOTE: When using the SIM card from a cellphone, this is the PIN number of the SIM card, NOT the PIN number of the cellphone!		
	A NOTE: When using the SIM card from a cellphone, this is the PIN number of the SIM card, NOT the PIN number of the cellphone!		
APN	NOTE: When using the SIM card from a cellphone, this is the PIN number of the SIM card, NOT the PIN number of the cellphone! GPRS Access Point Name, provided by the SIM card supplier.		
APN Username Password	ANOTE: When using the SIM card from a cellphone, this is the PIN number of the SIM card, NOT the PIN number of the cellphone! GPRS Access Point Name, provided by the SIM card supplier. GPRS login details, provided by the SIM card supplier.		
APN Username Password Message Centre	ANOTE: When using the SIM card from a cellphone, this is the PIN number of the SIM card, NOT the PIN number of the cellphone! GPRS Access Point Name, provided by the SIM card supplier. GPRS login details, provided by the SIM card supplier. SMS message centre number, provided by the SIM card provider.		

Setup

5.4.4 LOCATION

This is the location of the Site and the location that is used by the DSEWebNet $\mbox{\ensuremath{\mathbb{R}}}$ service when placing the Site Icon onto the world map.

DSE DSE 0890-01 Gatewa	ay		192.168.1.100 27/03/2014 14:11:27 V3.0.27
Status	Info Network GSM Location	IO Time File System	
	Latitude	54.176182	
Configuration	Longitude	-0.311576	
Modules Connection	Get Location from GPS		
		Apply	
Save Config			

Parameter	Description		
Latitude	Manually entered location of the Site.		
Longitude			
	A NOTE: Latitude and Longitude must be entered as decimal values (not degrees, minutes, seconds).		
Get Location From GPS	\square = GPS is used to determine the site location for positioning the site on the World map in the DSEWebNet [®] server. Additionally this location is used for the		
(DSE890 Ethernet Gatewav® onlv)	Geofence function, to alert users when the DSE890 Ethernet Gateway [®] moves outside the configured Geofence.		
	If no GPS signal is located, the manually entered location is used.		
	\Box = Location is manually entered.		
Apply	Click Apply to register the settings then click Save Config to restart the		
	DSEGateway [®] and connect with the new settings.		

5.4.5 I/O

Allows configuration of the DSEGateway® I/O (Inputs/Outputs)

Status	Info	Network Location IO Time File System			192.168.1.200 25/02/2014 12:10:08 V3.0.27
	Index	Name		10	
Configuration		Fuel Tampered with	In	~	
Madulas Connection	2	Digital IO B	Out	~	
	3	Digital IO C	Out	~	
	4	Digital IO D	Out	~	
		Apply			

Parameter	Description
Name	Enter the name that to identify the I/O channel on the DSEWebNet® system.
I/O	Select the type of the I/O
	<i>In:</i> The selected channel is an Input. Connect it's respective terminal to battery positive to activate it. The DSEWebNet [®] system shows the state of this input. <i>Out:</i> The selected channel is an Output. The DSEWebNet [®] system is used to activate/deactivate the Output.

5.4.6 TIME

Allows configuration of the DSEGateway® real time clock.

DSE DSE 0891-01 Gatewa	У		192.168.1.200 25/02/2014 12:17:21 V3.0.27
Status	Info Network Location IO Ti	ime File System	
Configuration Modules Connection	Date: (dd/mm/yy) Time: (hh/mm/ss) Period 24h Format	25 / 02 / 14 12 : 17 : 16 pm ✓ Get time Apply	Click to set the DSEGateway clock to the same time as your PC clock.

5.4.7 FILE SYSTEM

DSE DSE 0891-01 Gateway		192 168 1 200 25/02/2014 12·19·14 V3 0 27
Status	Info Network Location IO Time File System	
Configuration	Format file system	Format
Modulos Connection	Firmware Upgrade 0.0.23	Upgrade
	Restart Gateway	Restart
Parameter	Description	
Format File System	DSEGateway [®] how to communicate with conne this file system is empty. The DSEGateway [®] do depending upon which controllers are connecte automatic.	cted DSE controllers. Initially, wnloads templates as required d to it. This operation is
	Occassionally it may be desired to erase any stu DSEGateway [®] , which forces the download of ne This can be performed for example if updates a DSE Technical Support advise this to be perform	ored templates from the ew templates when required. re made to the templates and med.
	This erases all 'template' files from the DSEGat templates are downloaded automatically from the time a module is connected.	eway [®] . The latest version ne DSEWebNet [®] Server next
Firmware Upgrade	Allows "Over The Air" (OTA) updates to the firm	ware of the DSEGateway [®] .
	Select the required version and click Upgrade.	This requires an active
	connection to the DSEWebNet [®] service.	
Restart Gateway	Reboots the DSEGateway®. This is necessary a	after a Firmware Upgrade.

057-165 ISSUE: 9.0

5.4.8 BOOTLOADER UPGRADE

ONOTE: This process resets the DSEGateway[®] to factory settings.

Factory Settings		
IP Address	Username	Password
192.168.1.100	Admin	Password1234

The *Bootloader* is a small program within the DSEGateway[®] that handles the updating of the firmware within the device. Sometimes it may be necessary to update the Bootloader before the firmware can be updated. Bootloader upgrade files are available from Deep Sea Electronics PLC technical support.

For example, to update from Version 1 or Version 2 firmware to Version 3, the Bootloader must first be updated.

To do this Bootloader and Firmware update files are required as follows:

Description	DSE890 3G DSEGateway	DSE891 Ethernet Gateway
Bootloader update file	0890-01.bin	0891-01.bin
Firmware update files	A890-01.bin	A891-01.bin
	E890-01.bin	E891-01.bin

A USB flash memory stick formatted to *FAT* is also required. See Section entitled *How to Format a USB Flash Memory Stick to FAT*, elsewhere in this document.

To update the Bootloader:

- Place the Bootloader update file onto the memory stick.
- Remove the DC power supply from the DSEGateway[®].
- Insert the memory stick into the DSEGateway[®].
- Reapply the DSE power supply to the DSEGateway[®].
- Wait for the four status LEDs to stop cycling, then briefly remain green. The link LED status will remain RED whilst communications to DSEWebnet[®] are restabilished.
- The Bootloader updater file has been transferred to the DSEGateway[®].
- Remove the DC power supply from the DSEGateway[®].
- Remove the memory stick from the DSEGateway[®].
- Reapply the DSE power supply to the DSEGateway[®].
- The DSEGateway[®] Bootloader has been updated.
- Proceed to update the firmware as below.



stick inserted into the DSEGateway[®]

5.4.9 FIRMWARE UPGRADE

When available, firmware upgrade files are available from Deep Sea Electronics PLC website www.deepseaplc.com.

To do this, Firmware update files are required as follows:

Description	DSE890 3G DSEGateway	DSE891 Ethernet Gateway
Firmware update files	A890-01.bin	A891-01.bin
	E890-01.bin	E891-01.bin

A USB flash memory stick formatted to *FAT* is also required. See Section entitled *How to Format a* USB Flash Memory Stick to FAT, elsewhere in this document.

To update the Firmware:

- Place the Firmware update files onto the USB memory stick.
- Remove the DC power supply from the DSEGateway[®].
- Insert the memory stick into the DSEGateway[®].
- Reapply the DSE power supply to the DSEGateway[®].
- Wait for the four status LEDs to stop cycling, then briefly remain green. The link LED status will remain RED whilst communications to DSEWebnet[®] are restabilished.
- Remove the USB memory stick.
- The DSEGateway® Firmware has been updated.

5.4.10 HOW TO FORMAT A USB FLASH MEMORY STICK TO FAT

- Insert memory stick into PC USB port.
- Browse to *Computer* in Windows Explorer.
- Identify the memory stick, *Right Click* the device and select *Format*.
- Select *FAT* and click *Start*.



5.5 MODULES CONNECTION

5.5.1 DSEWEBNET

This page configures how the DSEGateway® communicates wih the DSEWebNet® server.

NOTE: A maximum of 5 connections can be made in the DSE WebNet page. That is a maximum of 5 controllers are supported on DSEWebNet[®] by each DSEGateway[®].

ANOTE: If a Port is used in the Modbus section, it cannot be used to create a DSEWebNet® Connection.

NOTE: RS232 is a *single master, single slave* system. This means that only one entry must be created for RS232 in the *Port* column.

NOTE: USB is a *single master, single slave* system. This means that only one entry must be created for USB in the *Port* column.



Parameters described overleaf.

Parameter	Description
Historic upload	Determines the period at which the DSEGateway® uploads its datalog to the
interval	WebNet server.
	Shorter upload intervals increase the number of connections to the
	DSEWebNet® Server and may increase data costs depending upon the
	service contract with the internet provider.
Historic Snapshot	Where Data Resolution is configured to be Snapshot, this determines the
Interval	period at which the DSEGateway® uploads a snapshot of the instrumentation to
	the WebNet server.
	Shorter upload intervals increase the number of connections to the
	DSEWebNet® Server and may increase data costs depending upon the
	service contract with the internet provider.

5.5.1.1 MASTER

These are the settings of the DSEGateway® port that is used to connect to the DSE controller).

Parameter	Description						
ID / IP	When Port is set	to <i>Ethernet</i> – IP	address of the se	elected controlle	r		
	When Port is set	to RS232/RS48	5 – Modbus slave	address of the	selected		
	controller. where	multiple devices	s are connected (F	(19485), a uniqu	e ID must be		
Dort	This is the part the	troller.	the DCC contro	llor			
POIL	This is the port that	at is connected		mer.			
	RS232: Connectio	on to a single co	ntroller via RS23	2 NULL Modem	(crossover)		
	cable with female	9 pin D connect	or terminations.		(,		
	RS485: Connectio	on to one or mo	re RS485 enabled	controllers usir	ng suitable		
	RS485 connectior	n cable.			5		
	Ethernet: Connect	ction to an Ether	net network of on	e or more contr	ollers.		
	USB: Single conn	ection to a supp	orted DSE contro	oller by USB A –	USB B cable.		
TCP Port/Baud	When Port is set	to Ethernet – TO	CP port to use for	Modbus (usuall	y 502). Each		
	separate entry mu	ist use a unique	port number.				
	When Port is set	to RS232/RS48	5 – Baud rate of t	he selected con	troller.		
Data Resolution	High, Medium, Lo	ow, Snapshot					
	I his sets the level	at what the DS	EGateway [®] class	es as a change	in value. The		
	DSEGateway®mc	onitors the control	oller's data and cr	hanges are logg	ed in its		
	Internal memory.	Selecting a nigh	er resolution leve	I increases the a			
	logged data, nenc	e increasing the	e amount of data t	nat is sent to the	e vvebinet		
	server. This may i	ncrease data co	sts depending up	on the service of	contract with		
	the internet provid	ier.					
	Data is logged wh	ere the value ch	anges by the cor	figured amount	If there is no		
	change in the data	a there is no da	ta to record in the	log Any logge	d data is		
	uploaded to the D	SE WebNet Sei	ver at the <i>Historic</i>	c Upload Interva	A This may		
	result in 'empty' re	eports if there is	no logged data to	o upload.	in this may		
	1.5						
	Data	High	Medium	Low	Snapshot		
	Resolution	•					
	Factory setting	1%	5%	10%	See Below		
		-	•		I		
	Snapshot: Where Data Resolution is configured to be Snapshot, this determines						
	the period at whic	h the DSEGate	way® uploads a sr	apshot of the in	strumentation		
	to the WebNet ser	rver, regardless	of how much it ha	as changed. Thi	s setting		
	prevents 'empty re	eports' that occu	ır where no data i	s logged due to	values		
	changing by small amounts, below the setting of the Data Resolution.						

5.5.1.2 LOCATION

Parameter	Description
Use GPS	\Box = Location of the controller is entered manually. Where multiple controllers
(DSE890 3G	are connected to the DSE890, it may be more appropriate to enter the location
Gateway only)	of each device manually. This allows each controller to show on the map at its
	Specific location instead of showing all controllers at the same location as the
	\square = GPS location is transmitted to the DSEWebNet [®] Server. This is used for
	live tracking and the Geofence feature of the DSEWebnet® system.
Latitude	Manually entered location of the selected controller.
Longitude	This is useful in cases where the controller is located some distance from the
	Gateway.
	For example the generator house may be at one side of a site, with the
	generator house shows this location on the DSEW/ebNet man, rather than the
	location of the IT department.
	Manually entered location (in degrees) of the DSE890
	Locations East of the Greenwich Meridian – positive
	Locations West of the Greenwich Meridian = pegative
	Locations North of the Equator = positive
	Locations South of the Equator = negative
	For example
	54.18° N, 0.31° W is entered as
	Latitude: 54.18
	Longitude: -0.31

5.5.2 CUSTOM INSTRUMENTS

This section is used to provide additional instruments to the DSEWebNet[®] system. The DSEGateway[®] is configured to read additional instruments from the connected controller(s). This information is then available for selection and display in the DSEWebNet[®] system.

DSE DSE 0891-01 Gateway	y							192.168.1	1.200 15/10/	2014 10:11:3	5 V3.1.10
Status	DSE Webne	t Custom Inst	ruments Modbus	1							
Configuration	Module	ndex:	1	~							
Madulas Consection	Index	Page	Offset	Sign		Size		Delete			
	New:			Unsigned	✓ 16		~	Apply			
	Import	Export									

Parameter	Description
Module Index	This refers to the <i>Index</i> column of the <i>DSEWebNet</i> configuration page.
	For example:
	Select <i>Module Index: 1</i> to add/edit the Custom Instruments for the Module
	configured under Index 1 in the DSEWebNet page.
Index	Index of the <i>Custom Instrument</i> . This is used when selecting the Custom
	Instrument for display in the DSEWebNet system.
Page	Modbus Page number to read from.
Offset	Register offset of the instrument to read.
Sign	Type of the register to read. This must match the sign of the register as
	documented in the DSE Gencomm protocol document (<i>bits/sign</i> column).
	Signed: The register is a signed value (register contains negative and positive
	Unsigned : The resister is unsigned (register contains positive values only).
Size	The size of the instrument value (in bits). This must match the <i>bits</i> of the
	register as documented in the DSE Gencomm protocol document (<i>bits/sign</i>
	column).
	16: The instrument is contained within a single register (16 bits).
	32: The instrument is contained within two registers (32 bits).

Example overleaf.

Exam	ples:			For this exa adding cus instruments values from	ample we are tom s to display		
Index	ID/IP	Ma Port	ster	the DSEW	in <i>Index 2</i> on ebNet page.	ngitude	
11	4	UU.	115200	High	54.176342	-0.311024	Delete
2	1	RS485	115200	High	54.176542	-0.311020	Delete
3	2	RS485	115200	High	54.176581	-0.311040	Delete
4	3	RS485	115200	High	54.176662	-0.311087	Delete
Add:		RS232 🗸	9600 🔽	Medium 💙	54.176582	-0.311036	Apply
			a). (1)			_	

Setup

Module	e Index:	2			
Index	Page	Offset	Sign	Size	Delete
1	4	2	Signed	16	Delete
2	5	2	Unsigned	16	Delete
New:			Unsigned 🗸	16 🗸	Apply
Import	t Export				

Module Index: 2 The items below are Custom Instruments from the module reffered to in Index 2 on the DSEWebNet page.

Example 1:

Index: 1 in the screenshot above

From the DSE Gencomm protocol document, the following shows the location of the "Oil Temperature" instrument which is read from the CAN ECU of engines that support this feature. This is taken from *Page 4 – Basic Instrumentation*. Therefore the *Page* parameter is set to "4".



Page 45 of 53

Example 2:

Index: 2 in the screenshot above

From the DSE Gencomm protocol document, the following shows the location of the "Fuel Pressure 1" instrument which is read from the CAN ECU of engines that support this feature.

This is taken from Page 5 - Extended Instrumentation. Therefore the Page parameter is set to "5".

Register offset	Name		Minimum value	Maximum value	Scaling factor	Units	Bits/ Sign
5	Fuel Pressure 1		0	10000	1	kPa	16
Offset p set to m first reg instrum case 5.	parameter is hatch the ister for the ent, in this	This mean the DSE of controller When sele display in select "1" display it "100" for t display it	ns that every controller as records kPa ecting this in the DSEWel for the <i>Scala</i> as kPa. Alter he <i>Scalar</i> pa as Bar (1 bar	1 kPa is stor "1" (ie the DS). strument for bNet system, ar parameter natively select trameter to r =100 kPa).	to	Sign parar Unsigned. identified b the "S" afte of bits. Size is set	neter is set to This is by the Lack of er the number to 16 bits.

5.5.3 MODBUS

NOTE: This section is only used when setting up the DSEGateway[®] to operate as a communications protocol convertor. This section must be left with no entries if using the DSEGateway[®] with the DSEWebNet[®] system.

NOTE: A maximum of 5 connections can be made in the *Modbus* page. That is a maximum of 5 controllers are supported for protocol conversion by each DSEGateway[®].

NOTE: Ports used in the *Modbus* section are dedicated to protocol conversion and cannot be used to connect a module to the DSEWebNet® system.

This page is used to configure the DSEGateway[®] as a Modbus Gateway to allow conversion across the various ports.

It can be used for example to set *USB* as a modbus master to connect to any DSE controller fitted with a USB port and supporting the DSE Configuration Suite SCADA function.



5.5.3.1 SLAVE

These are the settings of the DSEGateway® port this is connected to the monitoring device.

Parameter	Description
ID	Modbus slave address of the selected DSEGateway® port
Port	This is the modbus slave port that is connected to the Modbus Master (for example PC, Building Managmement System or PLC).
	RS232: Connection to the master via RS232. Check specifications of the master as to whether NULL MODEM (crossover) cable is required, RS485: Connection to the master via RS4852 and suitable RS485 cable. Ethernet: Connection to an Ethernet network accessible by the modbus master.
TCP Port/Serial	When Port is set to <i>Ethernet</i> – TCP port to use for Modbus (usually 502)
Baud	When Port is set to RS232/RS485 – Baud rate of the selected port.

5.5.3.2 MASTER

These are the settings of the DSEGateway® port that is used to connect to the DSE controller.

Parameter	Description
ID	Modbus slave address of the connected DSE controller
Port	This is the port that is connected to the DSE controller. RS232: Connection to a single controller via RS232 NULL Modem (crossover) cable with female 9 pin D connector terminations. RS485: Connection to one or more RS485 enabled controllers using suitable RS485 connection cable. Ethernet: Connection to an Ethernet network of one or more controllers. USB: Single connection to a supported DSE controller by USB A – USB B cable.
	A NOTE: RS485 is a <i>single master</i> system. This means that only one entry must be created for RS485 in the <i>Slave</i> column. Each entry in the <i>Master</i> column must communicate with controllers with unique Slave ID's.
	NOTE: RS232 is a <i>single master, single slave</i> system. This means that only one entry must be created for RS232 in the <i>Master and Slave</i> columns.
	A NOTE: Where multiple Ethernet connections are configured, each must utilise a unique port number.
TCP Port/Serial Baud	When Port is set to <i>Ethernet</i> – TCP port to use for Modbus (usually 502). When Port is set to <i>RS232/RS485</i> – Baud rate of the selected controller.

5.5.3.3 EXAMPLE OF MODBUS GATEWAY SETTINGS.

Sm	lave : nonito	The port connerring system	ected to the	Master : The port connected to the DSE controller			
	Slave Master						
Index	ID	Port	TCP Port / Serial Baud	ID/IP	Port	TCP Port / Serial Baud	Delete
1	10	Ethernet	502	1	USB	0	Delete
Add:		RS232 🗸	115200 🗸	0	USB Host 🔽	00	Apply

Index 1 is receiving modbus requests from the external monitoring system on **Ethernet**, **TCP Port 502**.

This is being transferred to the DSE controller via the **USB Host** port on the DSEGateway®

6 FAULT DIAGNOSIS

6.1 FREQUENTLY ASKED QUESTIONS

Factory settings IP Address : 192.168.1.100 Web Management Pages Port : 80 Username : Admin (case sensitive) Password : Password1234 (case sensitive) Password : Password1234 (case sensitive) I've forgotton my password and/or IP address Press and hold the reset pushbutton. All LEDs illuminate yellow gapin. Now release the button. Management pages cannot be accessed via remote connection The factory set LAN IP address is 192.168.100. Management pages cannot be accessed via remote connection The factory set LAN IP address is 192.168.100. Management pages cannot be accessed via remote connection The factory set LAN IP address is 192.168.100. Management pages cannot be accessed via direct connection to PC Check router and firewall settings are configured correctly to match this information. Remember that accessing the DSEGateway® remotely from the WAN (Ethernet) requires IP address of the broadband router to be entered into the PC browser. For easier trouble shooting, connect the DSEGateway®. Management pages cannot be accessed via direct connection to PC Check network connections. Check network settings. Ensure PC is on the same subnet as the DSEGateway®. Default IP address of the Gateway is 192.168.1.100 – Set the PC to 192.168.1.99 then enter http://192.168.1.100 – Set the PC to 192.168.1.99 then enter http://192.168.1.100 Port LEDs illuminate RED for a few success	Nature of Problem	Suggestion
Web Management Pages Port : 80 Username : Admin (case sensitive) Password : Password 1234 (case sensitive) I've forgotton my password and/or IP address I've forgotton my password and/or IP address Management pages cannot be accessed via remote connection Management pages cannot be accessed via direct connection to PC Management pages cannot be accessed via direct connection to PC Management pages cannot be accessed via direct connection to PC Check network connections. Check network connections. Check network settings. Check network settings. This is normal. The ports flash green when data is successfully received from the connected controller. Doring the startup sequence, the status LED illuminate RED. This is normal and if port setup and connections are correct, change to GREEN once communication is underway. Multiple LEDs remain RED This means that at least one of the configured conmunications ports is not receiving data from the connected controller. Check router and firewall settings. This means that at leastone of the configured conmunications ports i	Factory settings	IP Address : 192.168.1.100
Username : Admin (case sensitive) Password : Password 234 (case sensitive) I've forgotton my password and/or IP address Press and hold the reset pushbutton. All LEDs illuminate yellow again. Now release the button. The Gateway is now set back to factory settings. Management pages cannot be accessed via remote connection The Gateway is now set back to factory settings. Management pages cannot be accessed via remote connection The factory set LAN IP address is 192.168.100. Management pages cannot be accessed via remote connection The factory set LAN IP address is 192.168.100. Management pages cannot be accessed via direct connection to PC Check network connections. Remember that accessing the DSEGateway® remotely from the WAN (Ethernet) requires IP address of the broadband router to be entered into the PC browser. For easier trouble shooting, connect the DSEGateway®. Management pages cannot be accessed via direct connection to PC Check network settings. Ensure PC is on the same subnet as the DSEGateway®. Default IP address of the Gateway is 192.168.1.100 – Set the PC to 192.168.1.99 then enter http://192.168.1.100 – Set the PC to 192.168.1.99 then enter http://192.168.1.100 – Set the PC to 192.168.1.99 then sate connected controller. Port LEDs illuminate RED for a few seconds at power up of the DSE890. During the startup sequence, the startus LED illuminate RED. This is normal and if port setup and connection	· ····· · ····························	Web Management Pages Port : 80
Password : Password 1234 (case sensitive) I've forgotton my password and/or IP address Press and hold the reset pushbuton. All LEDs illuminate yellow, then cycle and finally illuminate yellow again. Now release the button. The Gateway is now set back to factory settings. Management pages cannot be accessed via remote connection The factory set LAN IP address is 192.168.100. Management pages are accessible via web browser on port 80. Check router and firewall settings are configured correctly to match this information. Remember that accessing the DSEGateway® remotely from the WAN (Ethernet) requires IP address of the broadband router to be entered into the PC browser. For easier trouble shooting, connect the DSEGateway® directly to a PC Ethernet port. Management pages cannot be accessed via direct connection to PC Check network connections. Check network settings. Ensure PC is on the same subnet as the DSEGateway®. Default IP address of the Gateway is 192.168.1.100 – Set the PC to 192.168.1.99 then enter http://192.168.1.100 – Set the PC to 192.168.1.99 then enter http://192.168.1.100 – Set the PC to 192.168.1.99 then enter http://192.168.1.100 – into the browser. Communication port LEDs are flashing GREEN This is normal and if port setup and connections are correct, change to GREEN once communication is underway. Multiple LEDs remain RED This means that at least one of the configured communications ports is not receiving data from the connected controller. Check all configured connections as for LED1, LED2 and LED3 detailed below. LED1 - LINK LED remains RED Check connection to broadband modem. Check conter and firewall settings.		Username : Admin (case sensitive)
I've forgotton my password and/or IP address Press and hold the reset pushbutton. All LÉDs illuminate yellow, then cycle and finally illuminate yellow again. Now release the button. The Gateway is now set back to factory settings. Management pages cannot be accessed via remote connection The factory set LAN IP address is 192.168.100. Management pages are accessible via web browser on port 80. Check router and firewall settings are configured correctly to match this information. Remember that accessing the DSEGateway® remotely from the WAN (Ethernet) requires IP address of the broadband router to be entered into the PC browser. For easier trouble shooting, connect the DSEGateway® directly to a PC Ethernet port. Management pages cannot be accessed via direct connection to PCC Check network connections. Check network settings. Management pages cannot be accessed via direct connection to PCC Check network settings. Management pages cannot be accessed via direct connection to PCC Check network settings. Management pages cannot be accessed via direct connection to PCC Check network settings. Management pages cannot be accessed via direct connection to PCC Check network settings. Management pages cannot be accessed via direct connection to PCC Check network settings. Management pages cannot be accessed via direct connection to PCC Check network settings. Management pages cannot be accessed via direct connection to PCC Check network settings. Management pages cannot be accessed via direct connection to PCC </td <td></td> <td>Password : Password1234 (case sensitive)</td>		Password : Password1234 (case sensitive)
addressyellow, then cycle and finally illuminate yellow again. Now release the button. The Gateway is now set back to factory settings.Management pages cannot be accessed via remote connectionThe factory set LAN IP address is 192.168.100. Management pages are accessible via web browser on port 80. Check router and firewall settings are configured correctly to match this information. Remember that accessing the DSEGateway® remotely from the WAN (Ethernet) requires IP address of the broadband router to be entered into the PC browser. For easier trouble shooting, connect the DSEGateway® directly to a PC Ethernet port.Management pages cannot be accessed via direct connection to PCCheck network connections. Check network settings. Ensure PC is on the same subnet as the DSEGateway®. Default IP address of the Gateway is 192.168.1.100 – Set the PC to 192.168.1.99 then enter http://192.168.1.100 into the browser.Communication port LEDs are flashing GREENThis is normal. The ports flash green when data is successfully received from the connected controller.Multiple LEDs remain REDThis means that at least one of the configured communications ports is no treceiving data from the connected controller.Multiple LEDs remain REDThis means that at least one of the configured communications ports is no treceiving data from the connected controller.LED1 - LINK LED remains REDCheck connection to broadband modem. Check conter and firewall settings.	I've forgotton my password and/or IP	Press and hold the reset pushbutton. All LEDs illuminate
release the button. The Gateway is now set back to factory settings. Management pages cannot be accessed via remote connection The factory set LAN IP address is 192.168.100. Management pages are accessible via web browser on port 80. Check router and firewall settings are configured correctly to match this information. Remember that accessing the DSEGateway® remotely from the WAN (Ethernet) requires IP address of the broadband router to be entered into the PC browser. For easier trouble shooting, connect the DSEGateway® directly to a PC Ethernet port. Management pages cannot be accessed via direct connection to PC Management pages cannot be accessed via direct connection to PC Check network connections. Check network settings. Ensure PC is on the same subnet as the DSEGateway®. Default IP address of the Gateway is 192.168.1.100 – Set the PC to 192.168.1.99 then enter http://192.168.1.100 – Set the PC to 192.168.1.99 then enter http://192.168.1.100 – Set the PC to 192.168.1.99 then enter http://192.168.1.100 – Set the PC to 192.168.1.99 then enter http://192.168.1.100 – Set the PC to 192.168.1.90 menotections are correct, change to GREEN Port LEDs illuminate RED for a few seconds at power up of the DSE890. During the startup sequence, the status LED illuminate RED. This is normal and if port setup and connections are correct, change to GREEN once communication is underway. Multiple LEDs remain RED This means that at least one of the configured comnections ports is not receiving data from the conneceted contr	address	yellow, then cycle and finally illuminate yellow again. Now
Management pages cannot be accessed via remote connectionThe factory set LAN IP address is 192.168.100. Management pages are accessible via web browser on port 80. Check router and firewall settings are configured correctly to match this information. Remember that accessing the DSEGateway® remotely from the WAN (Ethernet) requires IP address of the broadband router to be entered into the PC browser. For easier trouble shooting, connect the DSEGateway® directly to a PC Ethernet port.Management pages cannot be accessed via direct connection to PCCheck network connections. Check network settings. Ensure PC is on the same subnet as the DSEGateway®. Default IP address of the dateway is 192.168.1.100 – Set the PC to 192.168.1.99 then enter http://192.168.1.100 into the browser.Communication port LEDs are flashing GREENThis is normal. The ports flash green when data is successfully received from the connected controller. During the startup sequence, the status LED illuminate RED. This is normal and if port setup and connections are correct, change to GREEN once communication is underway.Multiple LEDs remain REDThis means that at least one of the configured communications ports is not receiving data from the connected controller. Check all configured connections as for LED1, LED2 and LED1 - LINK LED remains REDLED1 - LINK LED remains REDCheck conter and firewall settings. Check couter and firewall settings.		release the button.
Management pages cannot be accessed via remote connectionThe factory set LAN IP address is 192.168.100. Management pages are accessible via web browser on port 80. Check router and firewall settings are configured correctly to match this information. Remember that accessing the DSEGateway® remotely from the WAN (Ethernet) requires IP address of the broadband router to be entered into the PC browser. For easier trouble shooting, connect the DSEGateway® directly to a PC Ethernet port.Management pages cannot be accessed via direct connection to PCCheck network connections. Check network settings. Ensure PC is on the same subnet as the DSEGateway®. Default IP address of the Gateway is 192.168.1.100 – Set the PC to 192.168.1.99 then enter http://192.168.1.100 into the browser.Communication port LEDs are flashing GREENThis is normal. The ports flash green when data is successfully received from the connected controller.Port LEDs illuminate RED for a few seconds at power up of the DSE890.During the startup sequence, the status LED illuminate RED. This is normal and if port setup and connections are correct, change to GREEN once communication is underway.Multiple LEDs remain REDThis means that at least one of the configured communications ports is not receiving data from the connected controller. Check all configured connections as for LED1, LED2 and LED1 - LINK LED remains REDLED1 - LINK LED remains REDCheck conter and firewall settings.		The Gateway is now set back to factory settings.
accessed via remote connectionManagement pages are accessible via web browser on port 80. Check router and firewall settings are configured correctly to match this information. Remember that accessing the DSEGateway® remotely from the WAN (Ethernet) requires IP address of the broadband router to be entered into the PC browser. For easier trouble shooting, connect the DSEGateway® directly to a PC Ethernet port.Management pages cannot be accessed via direct connection to PCCheck network connections. Check network settings. Ensure PC is on the same subnet as the DSEGateway®. Default IP address of the Gateway is 192.168.1.100 – Set the PC to 192.168.1.99 then enter http://192.168.1.100 into the browser.Communication port LEDs are flashing GREENThis is normal. The ports flash green when data is successfully received from the connected controller.Port LEDs illuminate RED for a few seconds at power up of the DSE890.During the startup sequence, the status LED illuminate correct, change to GREEN once communication is underway.Multiple LEDs remain REDThis means that at least one of the configured communications ports is not receiving data from the connected controller.Multiple LEDs remain REDCheck connection to broadband modem. Check router and firewall settings.	Management pages cannot be	The factory set LAN IP address is 192.168.100.
port 80. Check router and firewall settings are configured correctly to match this information. Remember that accessing the DSEGateway® remotely from the WAN (Ethernet) requires IP address of the broadband router to be entered into the PC browser. For easier trouble shooting, connect the DSEGateway® directly to a PC Ethernet port.Management pages cannot be accessed via direct connection to PCCheck network connections. Check network settings. Ensure PC is on the same subnet as the DSEGateway®. Default IP address of the Gateway is 192.168.1.100 – Set the PC to 192.168.1.99 then enter http://192.168.1.100 into the browser.Communication port LEDs are flashing GREENThis is normal. The ports flash green when data is successfully received from the connected controller.Port LEDs illuminate RED for a few seconds at power up of the DSE890.During the startup sequence, the status LED illuminate RED. This is normal and if port setup and connections are correct, change to GREEN once communication is underway.Multiple LEDs remain REDThis means that at least one of the configured communications ports is not receiving data from the connected controller.LED1 - LINK LED remains REDCheck router and firewall settings.	accessed via remote connection	Management pages are accessible via web browser on
Check router and firewall settings are configured correctly to match this information. Remember that accessing the DSEGateway® remotely from the WAN (Ethernet) requires IP address of the broadband router to be entered into the PC browser. For easier trouble shooting, connect the DSEGateway® directly to a PC Ethernet port.Management pages cannot be accessed via direct connection to PCCheck network connections. Check network settings. Ensure PC is on the same subnet as the DSEGateway®. Default IP address of the Gateway is 192.168.1.100 – Set the PC to 192.168.1.99 then enter http://192.168.1.100 into the browser.Communication port LEDs are flashing GREENThis is normal. The ports flash green when data is successfully received from the connected controller.Port LEDs illuminate RED for a few seconds at power up of the DSE890.During the startup sequence, the status LED illuminate RED. This is normal and if port setup and connections are correct, change to GREEN once communication is underway.Multiple LEDs remain REDThis means that at least one of the configured communications ports is not receiving data from the connected controller. Check all configured connections as for LED1, LED2 and LED3 detailed below.LED1 - LINK LED remains REDCheck connection to broadband modem. Check router and firewall settings.		port 80.
to match this information. Remember that accessing the DSEGateway® remotely from the WAN (Ethernet) requires IP address of the broadband router to be entered into the PC browser. For easier trouble shooting, connect the DSEGateway® directly to a PC Ethernet port.Management pages cannot be accessed via direct connection to PCCheck network connections. Check network settings. Ensure PC is on the same subnet as the DSEGateway®. Default IP address of the Gateway is 192.168.1.100 – Set the PC to 192.168.1.99 then enter http://192.168.1.100 into the browser.Communication port LEDs are flashing GREENThis is normal. The ports flash green when data is successfully received from the connected controller.Port LEDs illuminate RED for a few seconds at power up of the DSE890.During the startup sequence, the status LED illuminate RED. This is normal and if port setup and connections are correct, change to GREEN once communication is underway.Multiple LEDs remain REDThis means that at least one of the configured communications ports is not receiving data from the connected controller. Check all configured connections as for LED1, LED2 and LED1 - LINK LED remains REDLED1 - LINK LED remains REDCheck conter and firewall settings.		Check router and firewall settings are configured correctly
Remember that accessing the DSEGateway® remotely from the WAN (Ethernet) requires IP address of the broadband router to be entered into the PC browser. For easier trouble shooting, connect the DSEGateway® directly to a PC Ethernet port.Management pages cannot be accessed via direct connection to PCCheck network connections. Check network settings. Ensure PC is on the same subnet as the DSEGateway®. Default IP address of the Gateway is 192.168.1.100 – Set the PC to 192.168.1.99 then enter http://192.168.1.100 into the browser.Communication port LEDs are flashing GREENThis is normal. The ports flash green when data is successfully received from the connected controller.Port LEDs illuminate RED for a few seconds at power up of the DSE890.During the startup sequence, the status LED illuminate RED. This is normal and if port setup and connections are correct, change to GREEN once communication is underway.Multiple LEDs remain REDThis means that at least one of the configured communications ports is not receiving data from the connected controller. Check all configured connections as for LED1, LED2 and LED1 - LINK LED remains REDLED1 - LINK LED remains REDCheck connection to broadband modem. Check router and firewall settings.		to match this information.
from the WAN (Ethernet) requires IP address of the broadband router to be entered into the PC browser. For easier trouble shooting, connect the DSEGateway® directly to a PC Ethernet port.Management pages cannot be accessed via direct connection to PCCheck network connections. Check network settings. Ensure PC is on the same subnet as the DSEGateway®. Default IP address of the Gateway is 192.168.1.100 – Set the PC to 192.168.1.99 then enter http://192.168.1.100 into the browser.Communication port LEDs are flashing GREENThis is normal. The ports flash green when data is successfully received from the connected controller. During the startup sequence, the status LED illuminate RED. This is normal and if port setup and connections are correct, change to GREEN once communication is underway.Multiple LEDs remain REDThis means that at least one of the configured communications ports is not receiving data from the connected controller. Check all configured connections as for LED1, LED2 and LED3 detailed below.LED1 - LINK LED remains REDCheck connection to broadband modem. Check router and firewall settings.		Remember that accessing the DSEGateway® remotely
broadband router to be entered into the PC browser. For easier trouble shooting, connect the DSEGateway® directly to a PC Ethernet port.Management pages cannot be accessed via direct connection to PCCheck network connections. Check network settings. Ensure PC is on the same subnet as the DSEGateway®. Default IP address of the Gateway is 192.168.1.100 – Set the PC to 192.168.1.99 then enter http://192.168.1.100 into the browser.Communication port LEDs are flashing GREENThis is normal. The ports flash green when data is successfully received from the connected controller.Port LEDs illuminate RED for a few seconds at power up of the DSE890.During the startup sequence, the status LED illuminate RED. This is normal and if port setup and connections are correct, change to GREEN once communication is underway.Multiple LEDs remain REDThis means that at least one of the configured communications ports is not receiving data from the connected controller.LED1 - LINK LED remains REDCheck connection to broadband modem. Check router and firewall settings.		from the WAN (Ethernet) requires IP address of the
For easier trouble shooting, connect the DSEGateway® directly to a PC Ethernet port.Management pages cannot be accessed via direct connection to PCCheck network connections. Check network settings. Ensure PC is on the same subnet as the DSEGateway®. Default IP address of the Gateway is 192.168.1.100 – Set the PC to 192.168.1.99 then enter http://192.168.1.100 into the browser.Communication port LEDs are flashing GREENThis is normal. The ports flash green when data is successfully received from the connected controller.Port LEDs illuminate RED for a few seconds at power up of the DSE890.During the startup sequence, the status LED illuminate RED. This is normal and if port setup and connections are correct, change to GREEN once communication is underway.Multiple LEDs remain REDThis means that at least one of the configured communications ports is not receiving data from the connected controller.LED1 - LINK LED remains REDCheck connection to broadband modem. Check router and firewall settings.		broadband router to be entered into the PC browser.
directly to a PC Ethernet port.Management pages cannot be accessed via direct connection to PCCheck network connections. Check network settings. Ensure PC is on the same subnet as the DSEGateway®. Default IP address of the Gateway is 192.168.1.100 – Set the PC to 192.168.1.99 then enter http://192.168.1.100 into the browser.Communication port LEDs are flashing GREENThis is normal. The ports flash green when data is successfully received from the connected controller.Port LEDs illuminate RED for a few seconds at power up of the DSE890.During the startup sequence, the status LED illuminate RED. This is normal and if port setup and connections are correct, change to GREEN once communication is underway.Multiple LEDs remain REDThis means that at least one of the configured communications ports is not receiving data from the connected controller.LED1 - LINK LED remains REDCheck connection to broadband modem. Check router and firewall settings.		For easier trouble shooting, connect the DSEGateway®
Management pages cannot be accessed via direct connection to PCCheck network connections. Check network settings. Ensure PC is on the same subnet as the DSEGateway®. Default IP address of the Gateway is 192.168.1.100 – Set the PC to 192.168.1.99 then enter http://192.168.1.100 into the browser.Communication port LEDs are flashing GREENThis is normal. The ports flash green when data is successfully received from the connected controller.Port LEDs illuminate RED for a few seconds at power up of the DSE890.During the startup sequence, the status LED illuminate RED. This is normal and if port setup and connections are correct, change to GREEN once communication is underway.Multiple LEDs remain REDThis means that at least one of the configured communications ports is not receiving data from the connected controller.LED1 - LINK LED remains REDCheck connection to broadband modem. Check router and firewall settings.		directly to a PC Ethernet port.
accessed via direct connection to PCCheck network settings. Ensure PC is on the same subnet as the DSEGateway®. Default IP address of the Gateway is 192.168.1.100 – Set the PC to 192.168.1.99 then enter http://192.168.1.100 into the browser.Communication port LEDs are flashing GREENThis is normal. The ports flash green when data is successfully received from the connected controller.Port LEDs illuminate RED for a few seconds at power up of the DSE890.During the startup sequence, the status LED illuminate RED. This is normal and if port setup and connections are correct, change to GREEN once communication is underway.Multiple LEDs remain REDThis means that at least one of the configured communications ports is not receiving data from the connected controller. Check all configured connections as for LED1, LED2 and LED3 detailed below.LED1 - LINK LED remains REDCheck connection to broadband modem. Check router and firewall settings.	Management pages cannot be	Check network connections.
Ensure PC is on the same subnet as the DSEGateway®. Default IP address of the Gateway is 192.168.1.100 – Set the PC to 192.168.1.99 then enter http://192.168.1.100 into the browser.Communication port LEDs are flashing GREENThis is normal. The ports flash green when data is successfully received from the connected controller.Port LEDs illuminate RED for a few seconds at power up of the DSE890.During the startup sequence, the status LED illuminate RED. This is normal and if port setup and connections are correct, change to GREEN once communication is underway.Multiple LEDs remain REDThis means that at least one of the configured communications ports is not receiving data from the connected controller. Check all configured connections as for LED1, LED2 and LED3 detailed below.LED1 - LINK LED remains REDCheck connection to broadband modem. Check router and firewall settings.	accessed via direct connection to PC	Check network settings.
Default IP address of the Gateway is 192.168.1.100 – Set the PC to 192.168.1.99 then enter http://192.168.1.100 into the browser.Communication port LEDs are flashing GREENThis is normal. The ports flash green when data is successfully received from the connected controller.Port LEDs illuminate RED for a few seconds at power up of the DSE890.During the startup sequence, the status LED illuminate RED. This is normal and if port setup and connections are correct, change to GREEN once communication is underway.Multiple LEDs remain REDThis means that at least one of the configured communications ports is not receiving data from the connected controller. Check all configured connections as for LED1, LED2 and LED1 - LINK LED remains REDCheck connection to broadband modem. Check router and firewall settings.		Ensure PC is on the same subnet as the DSEGateway [®] .
Intel PC to 192.168.1.99 then enter http://192.168.1.100into the browser.Communication port LEDs are flashing GREENPort LEDs illuminate RED for a few seconds at power up of the DSE890.Multiple LEDs remain REDMultiple LEDs remain REDMultiple LEDs remain REDLED1 - LINK LED remains REDCheck connection to broadband modem. Check router and firewall settings.		Default IP address of the Gateway is 192.168.1.100 – Set
Communication port LEDs are flashing GREENThis is normal. The ports flash green when data is successfully received from the connected controller.Port LEDs illuminate RED for a few seconds at power up of the DSE890.During the startup sequence, the status LED illuminate RED. This is normal and if port setup and connections are correct, change to GREEN once communication is underway.Multiple LEDs remain REDThis means that at least one of the configured communications ports is not receiving data from the connected controller.LED1 - LINK LED remains REDCheck connection to broadband modem. Check router and firewall settings.		the PC to 192.168.1.99 then enter http://192.168.1.100
Communication port LEDs are flashing GREENThis is normal. The ports flash green when data is successfully received from the connected controller.Port LEDs illuminate RED for a few seconds at power up of the DSE890.During the startup sequence, the status LED illuminate RED. This is normal and if port setup and connections are correct, change to GREEN once communication is underway.Multiple LEDs remain REDThis means that at least one of the configured communications ports is not receiving data from the connected controller.LED1 - LINK LED remains REDCheck connection to broadband modem. Check router and firewall settings.		into the browser.
Mashing GREEN Successfully received from the connected controller. Port LEDs illuminate RED for a few seconds at power up of the DSE890. During the startup sequence, the status LED illuminate RED. This is normal and if port setup and connections are correct, change to GREEN once communication is underway. Multiple LEDs remain RED This means that at least one of the configured communications ports is not receiving data from the connected controller. Check all configured connections as for LED1, LED2 and LED3 detailed below. Check connection to broadband modem. LED1 - LINK LED remains RED Check connection to broadband modem.	Communication port LEDs are	This is normal. The ports flash green when data is
Port LEDs infuminate RED for a few seconds at power up of the DSE890. During the startup sequence, the startus LED infuminate RED. This is normal and if port setup and connections are correct, change to GREEN once communication is underway. Multiple LEDs remain RED This means that at least one of the configured communications ports is not receiving data from the connected controller. Check all configured connections as for LED1, LED2 and LED3 detailed below. Check connection to broadband modem. LED1 - LINK LED remains RED Check connection to broadband modem.	Tiasning GREEN	Successfully received from the connected controller.
Seconds at power up of the DSE890. RED. This is normal and it port setup and connections are correct, change to GREEN once communication is underway. Multiple LEDs remain RED This means that at least one of the configured communications ports is not receiving data from the connected controller. Check all configured connections as for LED1, LED2 and LED3 detailed below. Check connection to broadband modem. LED1 - LINK LED remains RED Check connection to broadband modem.	Port LEDS illuminate RED for a few	During the startup sequence, the status LED illuminate
Multiple LEDs remain RED This means that at least one of the configured communications ports is not receiving data from the connected controller. Check all configured connections as for LED1, LED2 and LED3 detailed below. LED1 - LINK LED remains RED Check connection to broadband modem. Check router and firewall settings.	seconds at power up of the DSE690.	CED. This is normal and if port setup and connections are
Multiple LEDs remain RED This means that at least one of the configured communications ports is not receiving data from the connected controller. Check all configured connections as for LED1, LED2 and LED3 detailed below. LED1 - LINK LED remains RED Check connection to broadband modem. Check router and firewall settings.		underway
LED1 - LINK LED remains RED LED1 - LINK LED remains RED Check connection to broadband modem. Check router and firewall settings.	Multiple LEDs remain RED	This means that at least one of the configured
LED1 - LINK LED remains RED Check all configured connections as for LED1, LED2 and LED3 detailed below. Check connection to broadband modem. Check router and firewall settings.		communications ports is not receiving data from the
LED1 - LINK LED remains RED Check all configured connections as for LED1, LED2 and Check connection to broadband modem. Check router and firewall settings.		connected controller.
LED3 detailed below. LED1 - LINK LED remains RED Check connection to broadband modem. Check router and firewall settings.		Check all configured connections as for LED1. LED2 and
LED1 - LINK LED remains RED Check connection to broadband modem. Check router and firewall settings.		LED3 detailed below.
Check router and firewall settings.	LED1 - LINK LED remains RED	Check connection to broadband modem.
		Check router and firewall settings.
Check IP address, gateway, subnet mask and DNS		Check IP address, gateway, subnet mask and DNS
settings		settings
Check status of connection to host controller. The		Check status of connection to host controller. The
DSEGateway [®] does not communicate with the		DSEGateway [®] does not communicate with the
DSEWebNet® server if communications to the controllers		DSEWebNet® server if communications to the controllers
is not made.		is not made.
LED2 – USB LED remains RED This means USB communications is not successful.	LED2 – USB LED remains RED	This means USB communications is not successful.
Check settings of the DSEGateway [®] .		Check settings of the DSEGateway [®] .
Check USB cable is USB A to USB B type cable.		Check USB cable is USB A to USB B type cable.
Maximum length of USB cable is 6 m unless third party		IVIAXIMUM length of USB cable is 6 m unless third party
powered USB extender is used.		powered USB extender is used.
LEDS - KO400 LED REMAINS KED I INIS MEANS KO400 COMMUNICATIONS IS NOT SUCCESSIUI.	LEDS - KO400 LED remains KED	This means K5465 communications is not successful.
DSEC atoway® and all connected controllars		Check baue rate and slave ID settings of the
Doebaleway [®] and all connected controllers.		Doe Galeway and all connected controllers.
Relden 08/11) with termination resistors correctly fitted at		Belden 08/11) with termination resistors correctly fitted at
each end of the cable		each end of the cable

Nature of Problem	Suggestion			
	Max length of RS485 cable is 1.2km where correct cable			
	and termination resistors are fitted.			
LED4 – RS232 LED remains RED	This means RS232 communications is not successful.			
	Check baud rate and slave ID settings of the			
	DSEGateway [®] and connected controller.			
	Check RS232 wiring is Null Modem (crossover) type.			
	Max length of RS232 cable is 15m.			
GPS location is not accurate and/or	GPS location accuracy depends upon a lot of factors.			
GPS location moves around.	Best accuracy (typically around 10-20 metres) is achieved			
	when :			
	 Using a separate antenna (not combined with GSM) 			
	There is a clear view of the sky not obscured by			
	the control panel roof, tree coverage.or heavy			
	clouds.			
	There are no buildings close by, minimising a			
	wide angle view of the sky.			
Unable to add a gateway device.	Ensure the monitoring PC has access to			
"No connection" is reported.	realtime.dsewebnet.com. Ask the IT department to allow			
	this connection from the company internet connection.			

6.2 ADVANCED CONNECTION TROUBLESHOOTING

If GSM or Internet connection issues remain after following the above suggestions, an *Advanced* button on Status page is provided to aid troubleshooting.

For futher details, see the section entitled *Setup* | *Status* | *GSM* and/or *Setup* | *Status* | *Network* elsewhere in this document.

7 MAINTENANCE, SPARES, REPAIR, AND SERVICING

The module is designed to be *Fit and Forget*. As such, there are no user serviceable parts. In the case of malfunction, contact your original equipment supplier (OEM).

If additional plugs are required, please contact the DSE Sales department using the part numbers below.

Module Terr	minal Designation	Description	Part No.
1-6		6 way 5.08mm	007-446
	A B SCR	3 way 5.08mm	007-174

If antennae or USB cables are required, please contact the DSE Sales department using the part numbers below.

Connection	Description	Part No.
USB	USB A to USB B (DSEGateway® to host controller)	016-125
GSM (DSE890 3G only)	GSM Antenna	020-141
GPS (DSE890 3G only)	GPS Antenna	020-130
GSM & GPS (DSE890 3G only)	Combined GSM and GPS Antenna	020-150

8 WARRANTY

DSE provides limited warranty to the equipment purchaser at the point of sale. For full details of any applicable warranty, contact the original equipment supplier (OEM).

9 DISPOSAL

9.1 WEEE (WASTE ELECTRICAL AND ELECTRONIC EQUIPMENT)

Electrical and Electronic equipment must be stored, collected, treated, recycled and disposed of separately from other waste.



This Page Is Intentionally Blank

This Page is Intentionally Blank